



potentiometer



push button




toggle switch



BTN

GND


encoder



BTN

GND

BTN



GND  
SGN  
+5V

TO BOARD

FlightSimPM

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16



